

BNR Motorsports Ride Height Setup.

1. Have quad on flat surface
2. Have quad race ready tire pressure set and ready go.
3. Stand on pegs and have someone measure to bottom of foot peg bolt then under radiator or where rake in frame starts and take that measurement.

Good starting points for ride height in most models keep in mind this is with the common tire sizes for more info please contact us.

XC Front 7 1/2 (+/- 1/4) Rear 7 1/4 (+/- 1/4)

MX Front 7 1/2 (+/- 1/4) Rear 7 (+1/8)

TT Front 5 1/2 Rear 5 1/4

Please make sure you are measuring in the correct locations. If you are still having issues please contact us bnrmotorsports@hotmail.com

BNR Motorsports
11979 Market St
North Lima Oh 44452
(330) 549-9799