

BNR Motorsports

Plug and Play Pingel

7/8" or 1 1/8"

Fits Can-am ATVs 400cc-1000cc 2006 and up

Depending on your ATV, handle bar set and preference up will determine if you need a 7/8" or 1 1/8" kit. We will focus on the 7/8" on a Renegade 2007+ (other models will be similar)

1. Determine mounting location of your switch. (we will show the 7/8" on the left side of the bars)
2. Remove seat, front hood and dash panel.
3. Follow the stock left multifunction switch wiring from the bars to the connector under the gauge pod.
4. Unclip the factory connector (Circled in red) and connect the new connectors in between the factory wiring harness and multifunction switch.
5. Test the killswitch by starting ATV and pulling the red cord to make sure it stops the engine. Then reassemble

